6115.0780 ABANDONMENT OF WELLS.

The permittee shall notify the commissioner prior to abandoning, removing, covering, plugging, or filling the well or wells by means of which a water appropriation was made. The commissioner shall require abandonment procedures and methods consistent with the Minnesota Department of Health rules, parts 4725.2300 to 4725.3200.

Statutory Authority: MS s 103G.315; 105.415

Published Electronically: June 11, 2008