

1305.1608 SECTION 1608, SNOW LOADS.

Subpart 1. **Section 1608.2.** IBC Section 1608.2 is amended to read as follows:

1608.2 Ground snow loads. The ground snow loads to be used in determining the design snow loads for buildings and other structures are given in Minnesota Rules, chapter 1303.

Subp. 2. **Figure 1608.2.** IBC Figure 1608.2 on GROUND SNOW LOADS, p_g , FOR THE UNITED STATES (PSF) is deleted.

Subp. 3. [Repealed, 32 SR 7]

Statutory Authority: *MS s 16B.59; 16B.59 to 16B.76; 326B.101 to 326B.194*

History: *27 SR 1474; 32 SR 7; L 2007 c 140 art 4 s 61; art 13 s 4; L 2008 c 337 s 64*

Published Electronically: *February 23, 2009*