

**7011.0911 MAINTENANCE OF DRYER BURNER.**

Subpart 1. **Annual tuning of dryer burner.** The owner or operator of a hot mix asphalt plant must tune the dryer burner for maximum combustion efficiency once each calendar year.

Subp. 2. **Daily check of dryer burner.** The owner or operator of a hot mix asphalt plant must do the following while producing hot mix asphalt each day except when burning natural gas or propane:

- A. read the fuel pressure gauge on the dryer burner; and
- B. check for a negative draft at the dryer burner inlet.

Subp. 3. **Records kept on dryer burner.** The owner or operator of a hot mix asphalt plant must maintain a record of:

- A. the dates of the annual tuning of the dryer burner;
- B. the daily reading from the fuel pressure gauge on the dryer burner except when burning natural gas or propane;
- C. whether there was a negative draft at the dryer burner inlet each day except when burning natural gas or propane; and
- D. any corrective actions taken as a result of the daily checks required by subpart 2.

**Statutory Authority:** *MS s 116.07*

**History:** *20 SR 2253(NO. 42)*

**Published Electronically:** *February 25, 2008*